


Basement

Cycle and changing facilities




Not to scale. For indicative purposes only.

**THE
CURSOR
BUILDING**

38 CHANCERY LANE | MIDTOWN

Lower Ground Floor

6,047 sq ft / 561 sq m




Not to scale. For indicative purposes only.

**THE
CURSOR
BUILDING**

38 CHANCERY LANE | MIDTOWN

Ground Floor

4,675 sq ft / 434 sq m




Not to scale. For indicative purposes only.

**THE
CURSOR
BUILDING**

38 CHANCERY LANE | MIDTOWN

First Floor

10,310 sq ft / 957 sq m




Not to scale. For indicative purposes only.

**THE
CURSOR
BUILDING**

38 CHANCERY LANE | MIDTOWN

Second Floor

10,540 sq ft / 979 sq m




Not to scale. For indicative purposes only.

**THE
CURSOR
BUILDING**

38 CHANCERY LANE | MIDTOWN

Third Floor

10,581 sq ft / 983 sq m




Not to scale. For indicative purposes only.

**THE
CURSOR
BUILDING**

38 CHANCERY LANE | MIDTOWN

Fourth Floor

10,060 sq ft / 934 sq m




Not to scale. For indicative purposes only.

**THE
CURSOR
BUILDING**

38 CHANCERY LANE | MIDTOWN

Fifth Floor

7,721 sq ft / 717 sq m




Not to scale. For indicative purposes only.

**THE
CURSOR
BUILDING**

38 CHANCERY LANE | MIDTOWN

Sixth Floor

6,049 sq ft / 562 sq m



Not to scale. For indicative purposes only.

**THE
CURSOR
BUILDING**

38 CHANCERY LANE | MIDTOWN